

# Cooney Smart Coil Quick Installation Guide

## What's Included?



(a)

**Clips**


(One Per Valve)



(b)

**Sensor Leads**

(One Per Valve)



(c)

**Sensor Labels**



(d)

**Control Box**



(e)

**Panel Sticker**

## Quick Start

- 1 Locate all Freeze Block™ Valves on coils

Use the included sticker to indicate location of Coil Access Panels.



- 2 Install Clips (a) on to the valves

Freeze Block Valve™ must have Groove for install. If Coil was purchase before 2019, contact Cooney Coil.




- 3 Install Sensors Leads (b) into the clips

\*Optional\* Label each sensor with included sensor labels (3).




- 4 Mount Control Box (d) in desired location

Can be mounted inside or outside of AHU using the provided mounting hardware




## Quick Start (continued...)

- 5 Run Sensor leads (b) from the valve(s) to the Control Box (d)



- 6 Input Sensor leads (b) to Control Box terminal strips



- 7 Supply appropriate power to the control box (d)



- 8 Test each sensor for functionality and register Smart Coil for warranty coverage

Scan QR code to register Online, or fill out included warranty form and email to [info@cooneycoil.com](mailto:info@cooneycoil.com)



## Questions? Contact Us!

For additional questions and engineering support contact us:

(610) 783-1136

[info@cooneycoil.com](mailto:info@cooneycoil.com)

Cooney Engineered Solutions

20130 Valley Forge Circle

King of Prussia, PA | 19406

