

SMART COIL

QUICK START GUIDE

Need Help?
(610) 783-1136
info@cooneycoil.com

CONGRATS ON YOUR SMART COIL!

You're now one of many facilities that trust Freeze Block & Smart Coil to prevent freeze damage and keep operations running smoothly. With Smart Coil you can stay one step ahead with timely alerts, ensuring efficiency and peace of mind.

What's Included?



Clips
(One Per Valve)



Sensor Leads
(One Per Valve)



Control Box



Sensor Labels



Panel Sticker

SMART COIL

QUICK START GUIDE

Step 1: Locate All Freeze Block™ Valves

- Identify all Freeze Block™ Valves on your coils.
- Use the included sticker to indicate location of Coil Access Panel.




Step 2: Install Clips + Sensor Leads

- Secure the provided clips onto the valves.
- Insert sensor leads into the installed clips.
- Use optional sensor labels for easy identification.



Step 4: Mount Control Box

- Use included hardware for secure installation inside or outside of the AHU.



Step 5: Run + Connect Sensors

- Run sensor leads from valves to the control box.
- Insert sensor leads into the terminal strips of the control box.



Step 6: Power Up + Test

- Supply power to the control box to activate the Smart Coil system.
- Test sensors by pouring water over wire prongs to activate the alarm.
- Push the reset button to ensure the system resets properly.



Step 7: Get Your Warranty

Congrats, You Smart Coil Super Star!

- Snap a picture of the coil tag and control box installed.
- Send it to sales@cooneycoil.com to receive 48-month warranty documents and celebrate your install!



Send Us Your Pics

Need Help?
(610) 783-1136
info@cooneycoil.com